

Setting up Orange GPRS, WAP and MMS on a Pocket PC device

This article applies to the Pocket PC 2003 and Windows Mobile 5.0 platforms

Setting up the GPRS connection

Tap on **Start** and select **Settings**

Tap on the **Connections** tab at the bottom of the screen

Tap on the **Connections** icon

In the **My ISP** section, tap on the option to **Add a new modem connection**

In the **Name** field, type in **Orange GPRS**

In the **Modem** field, select **Cellular Line (GPRS)**

Tap **Next**

In the **Access Point Name** field, type in **orangeinternet**

Tap **Next**

Leave the **User Name**, **Password** and **Domain** fields blank

Tap **Finish**

Setting up the WAP connection

Tap on **Start** and select **Settings**

Tap on the **Connections** tab at the bottom of the screen

Tap on the **Connections** icon

In the **My Work Network** section, tap on the option to **Add a new modem connection**

In the **Name** field, type in **Orange WAP**

In the **Modem** field, select **Cellular Line (GPRS)**

Tap **Next**

In the **Access Point Name** field, type in **orangewap**

Tap **Next**

In the **User Name** field enter **orange**

In the **Password** field enter **Multimedia**

Leave the **Domain** field blank

Tap **Finish**

Setting up the MMS account

Tap on **Start** and select **Messaging**

Tap on the **Menu** button and select **MMS Configuration**

Tap on the **Servers** tab at the bottom of the screen

Tap on the **New** button

In the **Server Name** field enter **Orange MMS**

In the **Gateway** field enter **192.168.224.10**

In the **Port Number** field enter **9201**

In the **Server Address** field enter <http://mms.orange.co.uk>

In the **Connect Via** field, select **My Work Network**

Leave the rest of the fields at their default value.

Tap **OK**

Tap the **Set As Default** button

Tap **OK**

Your device has now been configured.